

This product may be used as a component in many types of systems allowing them to communicate wirelessly with other products such as PC-cards, laptops, handheld computers, mobile phones etc.

SPECIFICATIONS

Baud Rate:

Up to 115.2kbps (Recommend above 2.4kbps)

Supports 1.2/2.4/4.8/9.6/19.2/38.4/57.6/115.2kbps

Coverage:

Up to 100 M

Connection:

Point-to-Point

Signal:

DCD, TxD, RxD, GND, CTS/DSR1, DTR, RTS

RS-232 Interface:

D-SUB 9 Pin Female

Standard:

Bluetooth Specification Version 1.1

Frequency:

2.400~ 2.4835 GHz

Hopping:

1600/Sec, 1 MHz Channel Space

Modulation:

◀GFSK, 1 Mbps, 0.5 BT Gaussian

Tx. Power:

Max 20 /Typical 16 dBm (Class 1)

Rx. Sensitivity:

-84 dBm

Antenna Interface:

SMA Female

Antenna Gain Power:

Max 2 dbi


Power Supply:

+5 ~ +12 Vdc

Current Consumption:

Max 110 Ma

RS-232 INTERFACE



Signals

Pin# Signal Direction Description

1.....DCD Output.....Data Carrier Detect

2.....TxD..... Output.....Transmitted Data

3.....RxD InputReceived Data

4.....DSR..... N/A(input)Option: Data Set Ready

5.....GND N/A.....Sign Ground

6.....DIR Output.....Data Terminal Ready

7.....CTS Input.....Clear to Send

8.....RIS Output.....Request to Send

9.....Vcc Input.....Power Supply

FACTORY SETTINGS

The following is the factory settings of COM port.

You can change the factory settings of the COM

port with commands. In this case, you have to

remember the changed factory settings.

Baud rate: 9600 bps

Data Bit: 8 bit

Parity Bit: No parity

Stop Bit: 1 stop bit

Flow control: None

The default hardware configuration is for using

CTS.

STATUS LED

There are two LED's

OPR (Red): When supplied with power, it is turned on or flashing.

LNK (Green): When a wireless link is on, it is on. If in the configuration mode, it will be flashing every second.

RESET BUTTON

The Reset button has the following functions.

Enter/Exit the configuration mode

Restore the factory settings

Disconnect and reconnect a wireless connection

ENTERING THE CONFIGURATION MODE

When the LNK LED is OFF, push the RST button.

When the LNK LED is ON, you have to push the RST button twice to enter the configuration mode.

If you enter the configuration mode successfully, LNK LED will flash every second. And the COM port will be restored to the factory settings.

EXITING THE CONFIGURATION MODE

You can have two options to exit the configuration mode.

Exit the configuration mode by software: Type "X"

Exit the configuration mode by the RST button:

Push the RST button.

RE-CONNECTION

When the LNK LED is on, you can push the RST button to disconnect and reconnect a wireless link.

If you push the RST button, the COM port of HPS-120 will be stored the factory settings.

POWER SUPPLY

You can supply power to the HPS-120 as follows:

Use an AC/DC converter (Output Power: +5 ~ +12 Vdc / 300 mA)

Use a USB cable

Supply power via the 9th pin of the D-Sub 9-pin connector

INSTALLATION

1. Attached the antennae
2. Plug the unit into the COM port(s)
3. Power on
4. Adjust configuration (if necessary)

USAGE

You can change the configuration using Hyper Terminal.

Hyper Terminal Settings-

Baud Rate: 9600 bps / Data Bit: 8 / Parity Bit: None / Stop Bit: 1 / Flow Control: None / Emulation: VT100

STARTING CONFIGURATION

1. Plug into a COM port on the PC
2. Power on the PC
3. Open Hyper Terminal and set it up.
4. Push the RST button. If you enter the configuration mode successfully, the LNK LED will be flashing.
5. Press the <Enter> key, 5 seconds later.
6. Change the configuration with commands, if necessary.

COMMANDS AND USAGE REVIEW

If you are in the configuration mode, type "?<ENTER>" for a listing of commands. If you want to know the usage of a command, type "[command]<ENTER>" All commands and parameters are case sensitive. Do not use the <Backspace> key.

AFTER CONFIGURATION

After finishing the configuration, you have to execute a command "X" to apply the changes.

OPERATING INSTRUCTIONS

Item	Syntax	Description	Remarks
1. Connecting address	<u>A</u> <u>Addr</u> <CR>	Set a remote device address for a wireless connection.	A local and remote BD_ADDR always need to be difference.
2. Baud rate	<u>B</u> <u>B</u> <u>R</u> [<u>D</u>]<CR>	Change the baud rate. D (option): Change a factory setting ² .	Baud Rate (BR) - 0: 1200, 1: 2400, 2: 4800, 3: 9600, 4: 19200, 5: 38400, 6: 57600, 7: 115200
3. COM port	<u>C</u> <u>COM</u> <u>P</u> <u>o</u> <u>r</u> <u>t</u> <CR>	Change a request serial port.	COMPort: '1' ~ '7' Only valid in connection mode 2.
4. PIN code	<u>E</u> <u>P</u> <u>I</u> <u>N</u> <CR>	Authentication Off: hit <Enter> Authentication On: Type up to 11 characters	Paired adapters should have a same PIN code.
5. Flow control	<u>F</u> <u>F</u> <u>C</u> [<u>D</u>]<CR>	Set the Flow control. D (option): Change a factory setting ³ .	FC - 0: None 1: Hardware ⁴ 2: DTR/DSR ⁵
6. Search timer	<u>G</u> <u>T</u> <u>O</u> <CR>	Set a search timeout. TO (timeout): ASCII '0' ~ '999'	Connection mode 3 only. Default: 10 sec.
7. Max number of search	<u>H</u> <u>N</u> <u>O</u> <CR>	Set the max number of search. NO: ASCII '0' ~ '999'	Connection mode 3 only. Default: 10
8. Search device	<u>I</u> <u>T</u> <u>O</u> . <u>N</u> <u>O</u> <u>I</u> <u>L</u> <CR>	Execute searching devices. TO: ASCII '0' ~ '999' NO: ASCII '0' ~ '999' L (option): Display a long form.	Connection mode 3 only. ':: ASCII 0x2C
9. Discovery mode	<u>J</u> <u>E</u> <u>D</u> <CR>	Set the discovery mode. 'E': Enable 'D': Disable	Connection mode 1 only. Default: Enable
10. Low Power Mode	<u>K</u> <u>E</u> <u>D</u> <CR>	Set the low power mode. 'E': Enable 'D': Disable	Default: Disable

¹ If you push the RST button, the COM port will be stored the factory settings.

² If you change a factory setting for baud rate, you have to remember it.

³ If you change a factory setting for flow control, you have to remember it.

⁴ This is a flow control (will not be passed it over the air).

⁵ This is a flow control (will be passed it over the air).

11. Connection mode	<u>M</u> <u>Mode</u> <CR> ¹	Set a connection mode. Mode: '0' ~ '3' Mode 0 & 2: Required a remote address. Mode 2: Required a serial port.	0: 1:1 Mode 1: WAIT Mode 2: REGISTER and CONNECT Mode 3: WAIT Command Mode
12. Friendly name	<u>N</u> <u>Name</u> <CR>	Set a friendly name up to 11 characters.	
13. Parity Bit	<u>P</u> <u>P</u> <u>A</u> [<u>D</u>] ² <CR>	Set the parity bit. D (option): Change a factory setting ³ .	0: None, 1: Odd 2: Even
14. Connection Timeout	<u>Q</u> <u>T</u> <u>O</u> <CR>	Set the connection timeout. TO: ASCII '0' ~ '999'	Connection mode 3 only. Default: 10 sec.
15. Stop Bit	<u>S</u> <u>S</u> <u>T</u> <u>I</u> <u>D</u> <CR>	Set the stop bit. D (option): Change a factory setting ⁴ .	0: 1 Stop, 1: 2 Stop
16. Connect	<u>T</u> <u>Addr</u> . <u>T</u> <u>O</u> <CR>	Try to make a connection. Addr: a remote address TO (option): ASCII '0' ~ '999'	Connection mode 3 only. ':: ASCII 0x2C Default Timeout: 10 sec.
17. Cancel	<u>U</u>	Cancel a command.	Connection mode 3 only.
18. View	<u>V</u>	Display the device information	You can find out a software version.
19. CoD	<u>W</u> <u>C</u> <u>o</u> <u>D</u> <CR>	Set the class of device. CoD: 6-Hex in ASCII	Default: "001F00"
20. Exit	<u>X</u>	Apply changes.	Rebooting
21. Status	<u>Z</u>	Display the status of state machine.	'S': Idle / 'P': Pairing / 'C': Connecting / 'A': RF on / 'I': Inquiring
22. Usage	<u>?[C]</u> <CR>	Display the command list or usage. C: Command	AT+Z?<CR>: Command list AT+Z?A<CR>: Usage of 'A'

¹ <CR>: Carriage Return (0x0D)

² []: An optional parameter.

³ If you change a factory setting for parity bit, you have to remember it.

⁴ If you change a factory setting for stop bit, you have to remember it.