

OPERATION MANUAL




FIG.1



FIG.2




FIG.3

TO REPLACE THE BATTERIES

- Press button in the indicated direction with thumb, then put other finger near the slot and help to lift the lid up.(FIG.1)
- Take out the used batteries and replace new ones. (FIG.2)
- Replace battery cover.(FIG.3)

HOW TO REPLACE BULB

- Open the battery cover.(FIG.1)
- Remove damaged bulb.(FIG.2)
- Replace new bulb with its head downward.
- Apply light pressure to the bulb into firm position.
- Replace battery cover.(FIG.3)




FIG.1




FIG.2




FIG.3

TO REPLACE THE BATTERIES

- Press button in the indicated direction with thumb, then put other finger near the slot and help to lift the lid up.(FIG.1)
- Take out the used batteries and replace new ones. (FIG.2)
- Replace battery cover.(FIG.3)

Note:Replacement of LED is not recommended