Range: –58 to 302°F (–50 to 150°C)	 Slide the power "ON/OFF" switch to the "ON" position. Slide the power "ON/OFF" switch to the "OFF" position to conserve 	1.
Resolution 0.1° from –20.0 to 100°C Accuracy: ±1°C from –20 to 200°C	2. Slide the "C/F" switch to select the	2.
	desired reading. 3. Press "HOLD" button once to freeze the display. 6. Keep plastic housing and plastic handle away from heat source. Do not place inside oven or expose to open flame.	
	4. Press the "HOLD" button again to 7. Do not immerse probe handle or	

resume measurement.

7. Do not immerse probe handle or

cable in liquid.

OPERATION

SPECIFICATIONS

Use a coin to open the battery cover on back of unit. Replace with catalog number

BATTERY REPLACEMENT

1039.