

KEY FUNCTIONS

- ON/C** Turns the calculator on
Clears all calculator contents
(calculations, memory, etc.)
- M+** Adds the displayed value to
the memory
- M-** Subtracts the displayed value from
the memory
- MRC** First press recalls the memory total
Second press clears the memory total

AUTO POWER OFF

The calculator utilizes an auto power off feature which allows the elimination of the “power off” button. The calculator will automatically turn off after approximately six (6) minutes if no button has been pressed.

BATTERY REPLACEMENT

The primary power for the calculator comes from the solar cell; however, the backup battery will provide power for low light conditions. A faint display, no display in low light conditions, and missing segments are all indications that the backup battery must be replaced. Remove the battery cover, located on the back of the unit. Remove the exhausted battery and replace it with a new #389 silver oxide battery. Make certain to insert the new battery with the positive “+” size visible. Replace the battery cover.

WARRANTY OR SERVICE

For warranty or service contact:

TRACEABLE® PRODUCTS

12554 Old Galveston Rd. Suite B230
Webster, Texas 77598 USA
Ph. 281 482-1714 • Fax 281 482-9448
E-mail support@traceable.com • www.traceable.com

Traceable® Products are ISO 9001:2015 Quality-
Certified by DNV and ISO/IEC 17025:2017
accredited as a Calibration Laboratory by A2LA.

Cat. No. 6023 & 6026

©2018 Traceable® Products. 92-6023-00 Rev. 4 07172025

BIG DIGIT SOLAR-POWERED CALCULATOR INSTRUCTIONS