


PLEASE NOTE LASER RADIATION IS HARMFUL TO THE EYE, DO NOT LOOK DIRECTLY INTO THE APERTURE WHILE THE LASER IS IN OPERATION

USER INSTRUCTIONS

1. Your Laser Pointer uses two AAAA 1.5 volt batteries. We recommend alkaline batteries for longest life.


2. To change the batteries screw off the cap. Install the batteries with the positive pole of the battery up. Replace the cap.



3. To operate the pointer simply press on the plastic button. Releasing the button will turn the pointer off.

4. Remember that Laser pointer is a laser device and can be harmful if used improperly. Please KEEP OUT OF THE REACH OF CHILDREN.

5. If the body of the laser pointer becomes dull or tarnished you may clean the surface by using a clean cloth and alcohol.



**CAUTION-USE OF CONTROLS
OR ADJUSTMENTS OR
PERFORMANCE OF PROCEDURES
OTHER THAN THOSE SPECIFIED
HEREIN MAY RESULT IN
HAZARDOUS RADIATION
EXPOSURE.**

**WARRANTY, SERVICE, OR
RECALIBRATION**

For warranty, service, or recalibration, contact:

TRACEABLE® PRODUCTS

12554 Old Galveston Rd. Suite B230

Webster, Texas 77598 USA

Ph. 281 482-1714 • Fax 281 482-9448

E-mail support@traceable.com • www.traceable.com

Traceable® Products are ISO 9001:2018 Quality-
Certified by DNV and ISO/IEC 17025:2017
accredited as a Calibration Laboratory by A2LA.

**LASER POINTER
INSTRUCTIONS**