

SINGLE ACTION STOPWATCH INSTRUCTIONS

Usage

1. To begin timing, depress the crown.
2. To stop timing, depress the crown again.
3. Record the time.
4. To return to zero, depress the crown.

Maintenance

The internal spring of the stopwatch requires periodic winding to operate properly. To wind the stopwatch, turn the crown in a clockwise direction. Be careful not to overwind the spring as this could cause the spring to break.

Do not expose the stopwatch to liquids or a damp environment.

Warranty or Service

For warranty or service, contact:

CONTROL COMPANY

4455 Rex Road

Friendswood, Texas 77546 USA

Ph. 281-482-1714 Fax 281-482-9448

E-mail sales@control3.com www.control3.com

Control Company is ISO 9001 Quality-Certified by
DNV and ISO 17025 accredited as a Calibration
Laboratory by A2LA.

Control Company Cat. No. 92-8529-00 Rev. 0 051608

© 2008  **Control Company**